

JJR8000 Motor Soft Starter



- Advanced integrated protection: with various integrated protection and alarming functions. Nearly all the failures could be detected and displayed.
- Local bus communication system: there is an interface connecting to the Renle bus adapter in the front face of JJR8000 for the communication of bus adapter.
- All the working condition parameters could be displayed in the LCD screen.
- Many motors can be started in order and several sets of starting parameters could be stored for starting many motors.